


0-10V LED Dimmer / Wall Dimmer

Installation Instructions:

1. Switch off the circuit breaker for the intended installation area.
2. Remove any existing switch plate.
3. Make sure there is no power to the switch to be replaced.
4. Remove existing switch
5. Identify and disconnect power wires from switch.
6. Use the wiring diagram below to connect the dimmer with the 0-10V driver.
7. Carefully replace wiring back into wall box, mount the dimmer with supplied screws.
8. Install switch plate.
9. Switch power back on at circuit breaker



Wiring Diagram:



Installation Tips:

1. Install in accordance with all national and local electrical codes.
2. The max load of this dimmer is 600Watts.
3. Use copper power wires that are rated for least 75° Celsius/167° Fahrenheit.
4. CUT OFF ALL THE POWER CIRCUIT before start installation.
5. This product requires 0-10V driver.
6. Shorting output wires may cause damage to dimmer.
7. Always observe proper polarity when connecting power and load
8. For indoor use only